




开孔定位图




安装说明



①先取出挂架及挂架固定螺丝，将线穿过挂架；并用螺丝将挂架固定在 86 盒上。




②按装好挂架。




③取出 EIB 端子并将线连好。


Hole Positioning Diagram




Installation Instructions




① Remove the bracket and the screws used to fix the bracket, and pass the wires through the bracket. Then, use the screws to secure the bracket onto the 86-box.




② Install the bracket properly.




③ Remove the EIB terminal and connect the wires.




④将接好线的 EIB 端子插入设备。




④Insert the wired EIB terminal into the device.




⑤将设备推入向挂架，直到设备上的弹片卡入挂架卡扣内。




⑤ Push the device into the bracket until the spring clip on the device clicks into the bracket's latch.




⑥完成设备按装。
拆卸说明



⑥The device installation is now complete.
Disassembly Instructions



⑦取设备只需往外拉拔设备即可。



⑦To remove the device, simply pull it outward.